




ORDER OF OPERATIONS CHECK BOOK CASE


RECOMMENDED LEATHER WEIGHT

5oz exterior // 3oz interior

- 1. PRINT OUT THE PATTERN ON HEAVY CARD STOCK
- 2. CUT OUT THE PAPER PATTERN PIECES
- 3. TRACE THE PATTERN PIECES ONTO LEATHER
- 4. CUT OUT THE LEATHER PIECES
- 5. BURNISH ALL POCKET TOPS BEFORE ASSEMBLY
- 6. (OPTIONAL) GLUE BODY TO LINER, TRIM
- 7. (OPTIONAL) ATTACH SNAP STRAP TO BODY IN DESIRED LOCATION ALONG WITH SNAP HARDWARE
- 8. ATTACH PEN LOOP CENTERED ON THE OUTSIDE OF THE CASE + STITCH DOWN THE TWO LONG SIDES. WE RECOMMEND LEAVING A LITTLE ROOM FOR THE PEN BY ELEVATING THE CENTER OF THE PIECE OF LEATHER ABOUT 1/4"



9. GLUE POCKETS TO EITHER SIDE OF INTERIOR AND STITCH AROUND PERIMETER



- 10. TRIM AND FINISH EDGES AS DESIRED.
- 11. ENJOY :)

BODY

PRINT ACCURACY TEST

THE SOLID LINE SHOULD MEASURE 2 INCHES LONG

