
## Test Page

Select A4 in the paper size printing menu
Choose "actual size" in the printing preferences
Make sure these dimensions are correct
before starting your pattern




-7,17 inches







the pieces spread over multiple pages


paste the A, B and C pieces on the dotted line
















59-60 cm 23.2-23.6 in






## 59-60 cm 23.2-23.6 in






## -59-60 cm -23.2-23.6 in







59-60 cm 23.2-23.6 in

