




PRINTING INSTRUCTION

1. File > Print
2. Click on “Page Setup” button make sure your paper size is set to the paper size that you will print and Scale at 100%
3. In “Pages Sizing & Handling” click on “Size” button and select “Actual size”





IMPORTANT NOTE:

- **ADOBE ACROBAT READER (FREE SOFTWARE)** is recommended to open and print the patterns


link for free download

<https://get.adobe.com/reader>





Tile to page 1




CraftsmanGus : Pattern

Traveller's Book - L


Sta Oz 01-L #4mm.

Main Interior Panel

1.2 mm. Chrome Tanned Leather REC



X 2




CraftsmanGus : Pattern

Traveller's Book - L

Sta Oz 01-L #4mm.

Lining : Main Interior Panel





0.1-0.2 Polyester Lining



X 2



Tile to page 4







Tile to page 3



Button



Rivet





Tile to page 3

CraftsmanGus : Pattern


Traveller's Book - L

Sta Oz 01-L #4mm.


Main Interior Pocket

1.2 mm. Chrome Tanned Leather REC


X 1



Rivet



Rivet



Button

tsmanGus :
ern

er's Book - L
01-L #4mm.


terior Pocket

n. Chrome Tanned Leather REC

X 1




Rivet




Rivet



Button






Tile to page 4






Tile to page 8






Tile to page 7





Tile to page 7



CraftsmanGus : Pattern

Traveller's Book - L
Sta Oz 01-L #4mm.

Lining : Main Interior Pocket
0.1-0.2 Polyester Lining




X 1



Travel Book
Page 10 of 25

Tile to page 8




CraftsmanGus : Pattern

Traveller's Book - L
ta Oz 01-L #4mm.

Lining : Main Interior Pocket
1-0.2 Polyester Lining



X 1



CraftsmanGus : Pattern

Traveller's Book - L
Sta Oz 01-L #4mm.

Lining : Misc Pocket
0.1-0.2 Polyester Lining




X 1

Tile to page 12





Tile to page 11



Texon [or 0.1 mm drawing paper]

X1





Traveller's Book - L
Sta Oz 01-L #4mm.



Traveller's Book - L

Sta OZ 01-L #4mm.

Lining : Card Slot

0.1-0.2 Polyester Lining



Traveller's Book - L

Sta OZ 01-L #4mm.

Lining : Card Slot

0.1-0.2 Polyester Lining



Traveller's Book - L

Sta OZ 01-L #4mm.


Lining : Card Slot

0.1-0.2 Polyester Lining



Traveller's Book - L
Sta Oz 01-L #4mm.








CraftsmanGus : Pattern

Traveller's Book - L
Sta Oz 01-L #4mm.


Insert

1.2-1.5 mm. Chrome Tanned Leather REC



X 1

Tile to page 17




CraftsmanGus


Pattern


Traveller's Book - L

Sta Oz 01-L #4mm.
Insert : Button
1.2-1.5 mm. Chrome Tanned Leather REC

X1








CraftsmanGus : Pattern

Traveller's Book - L

Sta Oz 01-L #4mm.


Stiffener : Cover/Inside

Texon or Drawing Paper in 0.2-0.3 mm.



Stiffener (Hard)

X 2




Tile to page 21






Tile to page 20






CraftsmanGus : Pattern

Traveller's Book - L
Sta Oz 01-L #4mm.
Soft Cushion : Cover
0.2-0.3 mm.



X 2





Tile to page 23







Tile to page 22





Tile to page 22




CraftsmanGus : Pattern

Traveller's Book - L
Sta Oz 01-L #4mm.

Cover

1.8 mm. Chrome Tanned Leather REC



X 1



Tile to page 23

